



## PressurePro Solar Cleaner RM 99

Highly efficient, gentle and biodegradable detergent for residue-free and streak-free cleaning of solar and photovoltaic systems as well as glass surfaces.



### Properties

- Received the Pulire Innovation Award 2013
- For removing stubborn and greasy dirt
- Avoidance of limescale at all water hardness levels, even without switching using water softening systems
- residue-free, streak-free cleaning
- Reduces resoiling
- No damage to the solar and photovoltaic modules, the glass and plastic coatings, anodised or normal aluminium frames
- Gentle surface treatment thanks to improved sliding characteristics of the cleaning brushes
- DLG-tested (Deutsche Landwirtschafts-Gesellschaft e.V.)
- Very efficient
- Can be harmlessly drained into canalisation connected to the municipal waste water treatment plant
- Easily biodegradable (in line with OECD guideline)

### Application areas:

- Agriculture:** Solar and photovoltaic systems
- Building cleaning:** Solar and photovoltaic systems
- Industry:** Solar and photovoltaic systems

### Usage options

- High-pressure cleaner

Container sizes	Part number
10 l	6.295-798.0
20 l	6.295-799.0

pH



**Application:****High-pressure cleaner**

- Mix primary mixture.
- Pour cleaning solution into the cleaning device.
- Set the dosage and temperature on the device (application temperature max. 40°C).
- Apply cleaning agent solution with appropriate accessories to the surface to be cleaned and clean the surface from top to bottom.
- Rinsing with fresh water is not required.

**Instructions for use:**

- Do not apply to heated surfaces.
- Do not mix with other cleaning agents/chemicals.
- Store away from frost.
- Recommended storage and transport temperature: 0°C – 30°C.

**Warnings and safety recommendations according to EC Directives:**

- Warning
- H319 Causes serious eye irritation
- P280 Wear protective gloves/protective clothing/eye protection/face protection.
- P264 Wash thoroughly after handling.
- P305 + P351 + P338 IF IN EYES: Rinse cautiously with water for several minutes. Remove contact lenses, if present and easy to do. Continue rinsing.
- P337 + P313 If eye irritation persists: Get medical advice/attention.

**Further information:**

- Material Safety Data Sheet (MSDS)

**Dosage and yield:**

Contents:	Cleaning method:	Primary mixture:	Dosage:	Soiling:	Yield:
1000 ml	High-pressure cleaner	1+3	0.5-1 %	medium-strong	50-180 m <sup>2</sup>

Please contact us for more information:

**Alfred Kärcher SE & Co. KG**

Alfred-Kärcher Straße 28-40  
71364 Winnenden

Phone +49(0)7195-14-0  
Fax +49(0)7195-14-2212

[www.kaercher.com](http://www.kaercher.com)